

ReamoLink対応機種一覧

docomo(docomo FOMA)

NEC	富士通	パナソニック	シャープ	ソニーエリクソン
N-01A	F-01A	P-01A	SH-01A	SO703i
N-02A	F-02A	P-02A	SH-02A	SO704i
N-03A	F-03A	P-03A	SH-03A	SO705iA
N-04A	F-01A	P-01A	SH-01A	SO-01A
N-05A	F-01A	P-01A	SH-01A	SO-01A
N-06A	F-09A	P-06A	SH-06A	SO902iWP+
N-07A	F702iD	P-07A	SH-07A	SO903i
N-08A	F703i	P-08A	SH703i	SO903iTV
N-09A	F704i	P-09A	SH704i	SO905i
N703iD	F705i	P-10A	SH705i	SO905iCS
N705i	F706i	P703i	SH705iII	SO906i
N705iμ	F884i	P704i	SH706i	
N706i	F902i	P705i	SH706ie	
N706iII	F902iS	P705iCL	SH706iw	
N706ie	F903i	P705iμ	SH902i	
N901iC	F903iX	P706ie	SH902iS	
N901iS	F904i	P706iμ	SH902iSL	
N902i	F905i	P901iS	SH903i	
N902iL	F906i	P901iTV	SH903iTV	
N902iS		P902i	SH904i	
N902iX		P902iS	SH905i	
N903i		P903i	SH905iTV	
N904i		P903iTV	SH906i	
N905i		P903iX	SH906iTV	
N905iBiz		P904i		
N905iμ		P905i		
N906i		P905iTV		
N906iL		P906i		
N906iμ				

au

三洋	東芝	京セラ	ソニーエリクソン	日立	パナソニック
W51SA	biblio	K002	G9	H001	P001
W52SA	T001	misora	Premier3	W32H	W51P
W53SA	T002	NS01	re	W41H	W52P
W54SA	W47T	W43K	S001	W42H	W61P
W55SA	W52T	W51K	W32S	W43H	W62P
W62SA	W53T	W52K	W41S	W43HII	
W64SA	W54T	W61K	W43S	W51H	
	W56T	W65K	W44S	W52H	
	W61T		W51S	W53H	
	W62T		W52S	W61H	
	W64T		W53S	W62H	
	W65T		W54S	W63H	
			W61S		
			W62S		
			W64S		

SoftBank

三洋	東芝	京セラ	ソニーエリクソン
703SHf	814T	823P	830CA
804SH	815T	824P	930CA
810SH	830T	832P	
811SH	904T	920P	
812SH	911T	921P	
812SHs	912T	930P	
813SH	920T	931P	
814SH	921T		
815SH			
820SH			
904SH			
905SH			
910SH			
911SH			
912SH			
913SH			
920SH			
812SHsII			
821SH			
823SH			
824SH			
825SH			
830SH			
830SHs			
831SH			
831SHs			
920SH YK			
921SH			
923SH			
930SH			
931SH			
932SH			
933SH			
934SH			
935SH			